

LIST OF PARTS

We annex numbered list of parts (see Fig. 5) with shop names for the convenience of customers ordering duplicates or renewals. It is necessary when ordering to quote the shop number of the pump, which will be found typed on the steam cylinder cover.

No.	Part Name	Code Word
1.	Steam slide valve chest	VOPAZ
2.	Double joint	VOPBY
3.	Front stay	VOPCX
4.	Bottom spindle	VOPDW
5.	Valve gear levers	VOPEV
6.	Front stay bush	VOPEA
7.	Ball crosshead	VOPZT
8.	Main crosshead	VOPHO
9.	Crosshead pin	VOPIS
10.	Piston rod	VOPIQ
11.	Piston body	VOPKP
12.	Piston rings	VOPLN
13.	Cylinder cover	VOPML
14.	Discharge valve seat	VOPNI
15.	Suction valve seat	VOPOM
16.	Suction valve guide column	VOPPE
17.	Discharge valve guide column	VOPQD
18.	Discharge valve guide column cap	VOPRF
19.	Oil valves	VOPSU
20.	Bucket	VOPTB
21.	Bucket rings	VOPUH
22.	Pump cover	VOPVG
23.	Valve chest cover	VOPWK
24.	Steam stop valve	VOPXJ
25.	Exhaust stop valve	VOPYC
26.	Auxiliary valve spindle	VONJH
27.	Cylinder neck-ring	VONGQ
28.	Cylinder gland	VONFR
29.	Pump neck-ring	VONSE
30.	Pump gland	VONDT
31.	Pump gland studs	VONCA
32.	Cylinder gland studs	VONBU
33.	Top pins	VONAW
34.	Ball crosshead bushes	VONZB
35.	Piston rod nut	VONYC
36.	Pump rod nut	VONKM
37.	Crosshead fixing pin	VONWD
38.	Pump drain plug	VONVI
39.	Plunger lubricator	VONUO
40.	Lubricator coupling	VONTL
41.	Ball valves and springs for lubricator (not shown)	VONQV
42.	Gland packings complete	VONLF
43.	Pump and cylinder joints	VONRY
44.	Cylinder drain valve	VONPN
45.	Discharge valve spring	VONOK
46.	Relief valve (not shown)	VONMG

Sectional views of steam slide valve chest, with code words for parts, will be found on page No. 10. See also Code, pages 32 and 33.




FIG. 5