



# **Pipework**

# **Aims**

At the end of this session the student will have an understanding of the various considerations involved in the design and construction of pipelines.



# **Pipework**

- Materials
- Pipe specifications
- Handling of Pipework
- Pipe Bending
- Threading of Pipework
- Flanges (Types & Classifications)
- Gaskets
- Bolts & Studs
- Pipework Erection
- Testing
- Safe Dismantling



# **Pipework**

### **Introduction**

Domestic pipes are made from copper, plastic etc for clean products.

Pipework on chemical plants is used to transport large amounts of chemicals <u>safely</u> from one point to another.



### Why?

To accommodate a wide variety of conditions and chemicals pipework is made from different materials to different standards of specifications, for example

(a) Safety - to withstand pressures, temperatures and to be compatible with the various chemicals passing through them.

(b)Cost - i.e.. Chromium alloys (expensive) carbon steel may be adequate.




### **Materials:**

- Mild Steel
- Stainless Steel
- Cast Iron
- Copper
- Titanium
- Monel
- Inconel



### **Lined Pipework**





# **Why Are Pipes Lined?**

It may be cheaper or more practical to produce a lined pipe than a complete pipe made from more expensive materials for particular applications.

e.g. Brittle materials like glass or resins cannot withstand high pressure or shock.



# **Types of Linings**

- Rubber
- PTFE
- PVDF
- Alkathene
- Bitumen
- Lead
- Glass



# Pipe sizing

Pipe work is sized or identified by its Nominal Bore And wall thickness

### **Common NB sizes:**

1/4" NB	3" NB
3/8" NB	4" NB
1/2" NB	5" NB
3/4" NB	6" NB
1" NB	8" NB
1.1/2" NB	10" NB
2" NB	

©TTE Training Ltd.



# **Pipework Schedules**

Refer to the wall thickness of schedule 20, 40, 80 and 160 pipe, as the number increases so does the wall thickness.


The outside diameter remains constant, the bore diameter changes as the thickness increases.

Q. Why does the bore change and not the outside diameter?

A. To enable standard fittings to be used.



# **Pipe Schedules**





### PIPE FLANGES

Flanges are devices used to connect sections or lengths of pipe together.

For ease of installation pipe is normally supplied in 6mtr lengths, but many pipe configurations require many variations in length.

Also to allow items such as valves, pumps, filters etc to be fitted into the system.



# All Flanges Are Selected By Meeting Two Criteria:


# **Safety**

(Pipe material, size, process product, temperature, pressure)

# Cost



### **Types of Flange**






### **Flanges**

Flanges, like pipes, operate under varying conditions of temperature and pressure.

Standard maximum operating pressure and temperature ratings have been established for flanges and are expressed in pounds per square inch.




#### FLANGE DRILLING B.S.10 TABLE H



#### **All Dimensions in Inches**

Nom		Bolt Holes		
Size	0	No.	Dia.	P.C.D.
½ ¾ 1 1½ 2 3 4 6 8 10 12 14 16 18 20 21 24	4½ 4½ 4½ 5½ 6½ 8 9 12 14½ 17 19¼ 21¾ 24 26½ 29 30 33½	4 4 4 4 4 4 8 8 12 12 16 16 20 24 24 24	11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 7/8 7/8 1 1 1 1/8 1 1/8 1 1/8 1 1/8 1 1/4 1 1/4 1 1/4 1 1/4 1 1/4 1 1/4 1 1/8	3½ 3½ 37/16 37/8 41/8 5 6½ 7½ 10½ 12¾ 15 17½ 19½ 24 26½ 27½ 30¾

#### FLANGE DRILLING B.S.10 TABLE J




#### All Dimensions in Inches

Nom		Bolt Holes		
Size	0	No.	Dia.	P.C.D.
½	4½	4 4	11/16	3¼
¾	4½		11/16	3¼
1	4¾		11/16	3 <sup>7</sup> /16
1½ 1½	5¼ 5½	4 4	11/16 11/16 7/8	3 <sup>7/8</sup> 4 <sup>1/8</sup>
2	6½.	4	7/8	5
3	8	8	7/8	6½
4	9	8	7/8	7½
6	12	12	1	10¼
8	14½	12		12¾
10	17	12	1 1/8	15
12	19¼	16	1 1/8	17¼
14	21¾	16	1¼	19½
16 18	24 26½	20	11/4	21 ¾ 24
20	29	24	1 <sup>3</sup> /8	26½
21	30	24	1 <sup>3</sup> /8	27½
24	33½	24	1½	30¾



#### FLANGE DRILLING B.S.10 TABLE D



#### All Dimensions in Inches

Nom		Bolt Holes		
Size	0	No.	Dia.	P.C.D.
½ 1 1½ 2 3 4 5 6 8 9 10 12 14 15 16 18 20 21 24	3% 4 4% 4% 5% 6 7% 8% 10 11 13% 14% 16 18 20% 21% 22% 22% 25% 27% 29 32%	4 4 4 4 4 4 4 8 8 8 8 8 8 2 1 2 1 2 1 6 1 6 1 6 1 6	9/16 9/16 9/16 9/16 9/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/16 11/18	2 5/8 2 7/8 3½ 3 7/16 3 7/8 4½ 5¾ 7 8½ 11½ 12¾ 14 16 18½ 19½ 20½ 25½ 25½ 26½ 29¾

#### FLANGE DRILLING B.S.10 TABLE E



#### All Dimensions in Inches

Nom		Bolt Holes		
Size	0	No.	Dia.	P.C.D.
½ % 1 1½ 2 3 4 5 6 8 9 10 12 14 15 16 18 20 21 24	3¾ 44 4½ 4¾ 5¼ 6 7¼ 8½ 10 11 13¼ 14½ 16 18 20¾ 21¾ 22¾ 25¼ 27¾ 25¼ 27¾ 29 32½	4 4 4 4 4 4 4 4 4 8 8 8 8 8 2 12 12 12 12 16 16 16 16	9/16 9/16 9/16 9/16 9/16 11/16 11/16 11/16 7/8 7/8 7/8 7/8 1 1 1 1 1 1 1 1/8	2 5/8 2 7/8 3¼ 3 7/16 3 7/8 4½ 5¾ 7 8¼ 9¼ 11½ 12¾ 14 16 18½ 19½ 20½ 25½ 25½ 26½ 29¾




#### Welding neck flanges

Are identified by their tapered hubs which connect the flange to the pipe.

Usually used on high pressure installations

#### Slip on flanges


Fit onto the end of the pipe and are Fillet Welded into position, back and front.





#### **Screwed or Threaded Flanges**

Screwed onto the end of the pipe.




#### **Backing Flanges**

Used with lap joints stubs where frequent dismantling

for inspection and cleaning is necessary.


### **Socket Weld Flanges**

Are slipped onto the ends of pipes and Fillet Welded in position.






### **Flat Face**






### **Raised Face**






# Lapped





## Flange measurements





### **Gaskets**

A gasket of soft compressible material is fitted between two flanges to ensure a leak tight joint.

It is placed between the joint surfaces of the flanges and forms a seal when the joint is tightened.

Different types of gaskets, and materials from which gaskets may be made, are available to suit specified joint requirements.



# Depending on the application, the main requirement of a gasket may be any or all of the following:

**Hardness and Compressibility** 

**Resistance to Heat** 

**Resistance to Pressure** 

**Resistance to Corrosive Action** 

It is important that only the gasket specified is fitted otherwise the joint may fail after tightening.




### **Design Considerations When Selecting Joints**

- Line Product
- Temperature
- Pressure
- Materials
- Pipe Capacity
- Corrosion / Erosion
- Insulation Against Thermal Losses
- Friction
- Pipe Fittings
- Pipe Stresses i.e. Supports
- Pressure Drop



### **Gaskets**



#### **Full-Face Gaskets**

The full-face gasket is used with full-face flanges.

The connecting bolts pass through holes in the flanges and gasket.

Full-face gaskets are made from compressed asbestos fibre\*, or compressed asbestos fibre\* on a wire mesh or synthetic rubber.

\* Asbestos is now being replaced with a safe alternative material.



### **Joints**

#### The type of joint to be used depends on certain things:

- 1. Product.
- 2. **Temperature**.
- 3. **Pressure**.
- 4. Type of Flange Connection.

#### **Here Are Some Examples:**


Product	Max (operating) Temp	Type of Flange	Type of Gasket
Hydrocarbons Non Corrosive Liquids and Gases	340	ASA 150/300 Raised Face	CAF Jointing Oil Resistant
(Except - LPG. Ethylene, Fuel Gas, Natural Gas.)			
,	675	ASA 300/600 900/1500 Raised Face	Spiral Wound 316/CAF Fill
<b>Steam</b> Up to 35 kg/cm2	340	ASA 150/300 Raised Face	CAF Jointing Oil Resistant
Steam Up to 50 kg/cm2	400	ASA 300/600 Raised Face	Spiral Wound 316/CAF Fill

Pipe-work & Valves - 024



### **Joints**

### Forces being applied to a flanged joint





### Rubber

Applications - Low pressure systems, water, air, uneven flanges.

#### **Advantages -**

- Versatile.
- Good Resilience.
- Highly Impermeable.



#### **CAF(compressed asbestos fibre)**

Because of the asbestos content, care should be taken to avoid any dust, never file or grind.

#### **Thickness**

CAF has little tensile strength. At high pressures a wide joint is more likely to blow than a narrower one.

Will tolerate a wide range of chemicals, ie, Nitrogen, Chlorine, Hydrogen, some solvents, Steam and Oil

They will withstand temperatures of up to 510°C and pressures of up to 100-bar

All CAF joints should be marked with: a) The Makers Logo.

- b) The Flange Rating.
- c) Standard Number.

NOTE: Asbestos is an extremely hazardous material and has been replaced by safe alternatives However there are still old flanged joints in situ that may have a CAF gasket fitted



#### **SPIRAL WOUND JOINTS**

Work through construction:

Windings - Carbon Steel, Monel, Titanium, Nickel, Stainless Steel.

Fillers - Asbestos, Lead, PTFE, Masterite, Ceramic Fibres and Carbon.

#### **Function of the Rings**

- 1) Gives strength against line pressure.
- 2) Assists in centralising the joint.
- 3) Limits the amount of compression.



#### **PTFE**

#### **Advantages:**

- Chemically inert
- Easy to cut
- No dangerous particles

#### **Disadvantages:**


- Low co-efficient of friction
- Poor resilience (flows under load)
- Maximum temperature300°

#### PTFE can be strengthened by:

- a) Enclosing a steel mesh inside the gasket.
- b) Reinforcing the PTFE with glass, metal, etc.




#### **What Size Gasket?**



Offer the Joint up to the Flange Face it should look like this. With the outside of the joint just touching the bolt holes. The inside of the joint must not protrude into the Pipe Bore.

Pipe-work & Valves - 030





#### **Wrong**

Joint is too small, therefore, it is not central.


### **Wrong**

Joint is too large and is obstructing the bolt holes.

Pipe-work & Valves - 039




Some of the gaskets that you might find on site are:



The type with the guide ring should be used between flat or raised face flanges to ensure true centering and to limit the compression of the gasket.

In addition the guide ring provides extra radial strength and prevents the possibility of a gasket 'blow-out'.





The type with an inner guide ring is used on vacuum service.



#### **Spades**

#### **SPECTACLE PLATES**





When a spade is in place and needs turning you will have to remove more bolts to allow



#### **Spades**



Obviously the length of bolt will be longer when a spade needs to be inserted.
Always remember full nuts on each side of the bolt.

#### **Inserting a Spade:**

When a spade needs inserting or removing, it is not necessary to remove all the bolts.

#### **Remember This:**

Only remove one less than half the amount of bolts in the flange.

E.g. Flange with 4 bolts - Remove 1 Bolt

Flange with 8 bolts - Remove 3 Bolts




#### **Inside-Bolt Gaskets**

Inside-bolt circle gaskets are used with raised-face flanges.

These gaskets fit inside the ring of connecting bolts and against the raised faces of the flanges.

There are two main types of inside-bolt circle gaskets.




1) Raised-Face plain gaskets

These gaskets are made from compressed fibre or compressed fibre on wire mesh.



#### 2) Spiral-wound gaskets


These gaskets are made from spiral-wound metal and fibre tapes which are supported in a metal frame.






#### 3) Flat Ring gaskets

This type of gasket is used with tongue and groove flanges. The gasket is made of aluminium, copper or soft steel depending upon its application.








#### **Bolts**


Bolts and nuts are made from mild steel and have limited qualities of strength and durability. The use of bolts is therefore limited to low pressure lines.

#### **Stud Bolts**

These are made from higher quality steel than machined bolts and are used at higher pressures.









#### **Stud Sizes Given Without Spade**

RATING	•	150	3	800		600
Pipe Size	No of Bolts	<b>Bolt Size</b>	No of Bolts	<b>Bolt Size</b>	No of Bolts	Bolt Size
1/2	4	½ <b>X 2</b> ¼	4	½ <b>X 2</b> ½	4	½ x 3
3/4	4	½ <b>X 2</b> ¼	4	5/8 <b>X 2</b> <sup>3</sup> / <sub>4</sub>	4	5/8 <b>x 3</b> ½
1	4	½ <b>X 2</b> ½	4	5/8 <b>x 3</b>	4	5/8 <b>X</b> 3 ½
1 1/2	4	1/2 X 2 3/4	4	3/4 x 3 1/2	4	3/4 x 4
2	4	5/8 <b>x 3</b>	8	5/8 <b>x</b> 3 ½	8	5/8 <b>x 4</b>
3	4	5/8 <b>X</b> 3 ½	8	3/4 x 4	8	3/4 x 4 3/4
4	8	5/8 <b>x</b> 3 ½	8	3/4 x 4 1/4	8	7/8 <b>x</b> 5 ½
6	8	3/4 x 3 3/4	12	3/4 x 4 3/4	12	1 x 6 ½
6	8	3/4 x 4	12	7/8 <b>x 5</b> ½	12	1 1/8 x 7 ½
10	12	7/8 <b>x</b> 4 ½	16	1 x 6	16	1 1/4 x 8 1/4
12	12	7/8 <b>x</b> 4 ½	18	1 1/8 x 6 ½	20	1 1/4 x 8 1/2
14	12	1 x 5	20	1 1/8 x 6 3/4	20	1 5/8 x 9
16	16	1 x 5 1/4	20	1 1/4 x 7 1/4	20	1 ½ x 9 ¾
18	16	1 1/8 x 5 3/4	24	1 1/4 x 7 1/2	20	1 5/8 x 10 ½
20	20	1 1/8 x 6	24	1 ¼ x 8	24	1 5/8 x 11 1/4
24	20	1 1/4 x 6 3/4	24	1 ½ x 9	24	1 7/8 x 12 <sup>3</sup> / <sub>4</sub>



#### **Joint Making Procedure**

Ensure joint faces are clean, flat and have the correct surface finish.

Ensure that joint faces are aligned within specified limits.

External pressures should not be applied to align faces prior to bolting and joint face gap should be within specified limits.

Always use the specified jointing material.

Only use specified jointing compound and bolt lubrication.

Bolts should be of the correct specification and fitted in the correct sequence / procedure.

Bolt tension should be applied as specified.

Bolts should be the correct length.


No thread protrusion.

'Washering up' should be avoided.



#### **Anti - Seize**


Always use anti-seize it saves time in the long run. It is recommended that you only put anti-seize on one side of the bolt. The reason for this is, when the bolt is undone next time, only one nut will come off and this will save you time and effort.



Pipe-work & Valves - 042

©TTE Training Ltd.








#### **Alignment of Flanges**

It is important to align the flanges with each other. If they are not, all of the gasket

surface will not be used.




It is most critical that the male and female type of flanges are aligned so that they locate.



#### **Pulling Up The Flange**

The gasket must be compressed all the way round. It is important that the flange is pulled up squarely.





# Pipeline Specifications

On site there are many pipeline systems and they may look the same, so how do we identify them.

For example, a car has a registration plate, from that, reference to it's Make, Model, Year of manufacture, engine type etc can be Obtained.

Likewise with pipelines we need reference to identify its duty, situation, material spec, test and working pressures etc.

Each pipeline is given its own unique reference (number or letters)
This is called a **PIPELINE SPECIFICATION** 



Fluid Description	Main Pipe Material	Pressure Bar.G	Temperature	SPEC Reference
Air Compressed	C.S	10	50	AMA 004 A
Air Instrument	C.S	10	80	AGB 001 A
Air Instrument	ST.ST. 304L	10	80	SGB 003 A
Air Instrument	ST.ST. 316	10	80	SGD 003 A
Air Mask (Upto Receiver)	C.S	10	80	AMA 025 A
Air Mask (After Receiver)	ST.ST. 304L	7	60	SGB 017 A
Air Mask (After Receiver)	ST.ST. 316	7	60	SGD 017 A
Brine Refrigerated	CS	13.8	+150 -20	AGU 164 A
Dry Risers	CS	7	80	AMA 084 A
Natural Gas	C.S.	10	186	AMA 006 A
Nitrogen	C.S.	10	80	AGB 001 A
Steam Tracing for Wrapping Valves and Fittings	Small Bore Copper (Comp Fittings)	10	186	CZA 001 A
Steam Tracing Direct Clip On	CS	10	186	AMS 001 A
Steam Tracing Spacer	CS	10	186	AMS 002 A
Steam & Condensate L.P. (ANSI 150 Class 3)	CS	10	186	AMA 007 A
Steam & Condensate I.P. (ANSI 300 Class 2)	CS			AHB 007 A
Steam & Condensate H.P. (ANSI 600)	CS			ACB 002 A

#### PIPELINE REFERENCE NUMBER

This would be located on site drawings (construction drawings, Line diagrams) Stencilled or tabbed on the pipeline



Project No. T10009 Issue **Piping Systems Specification Index** Engineering Project Title. **Standards** Α Sheet 1 of 4 Pipe Issue Note No. 3117 Main Piping Material. Radiography Galvanising See Record Of Modifications Sheet Index Heat Treatment. Shop Test. Insulation. Jacketing. Ref. For Details Of Any Changes To Index Painting. Tracing. Gaskets. Flange. Fluid Pipe. Spec. Duty Ref. SP. 100% ACB002 A Steam and Condensate H.P. Up To 400° C CS ANS A106 Yes GR.B 600 lwnd. AGB001 A API5L ANS 10% Air - Instrument CS CAF Yes Nitrogen GR.B | 150 See 10% Brine - Refrigerated CS API5L ANSI CAF Yes Yes AGU164 A Fab. GR.B 150 Spec. AHB007 A Steam and Condensate I.P. CS API5L ANSI CAF 10% Yes Yes GR.B 1300 Water - Hot - High Pressure CAF Air - Compressed CS API5L ANSI AMA004 A Yes GR.B 150 API5L ANSI CAF AMA005 A CS Water: General Works After Yes Yes GR.B | 150 Break Tank - Non Potable API5L ANSI CS CAF AMA006 A **Natural Gas** Yes GR.B | 150 CS API5L ANSI CAF Yes AMA007 A Steam and Condensate L.P. Yes GR.B | 150 AMA025 A Air Mask - Up To Receiver CS API5L ANS Rub-Yes GR.B 150 -ber Α Issue 3 Sept 1990 Date

**EXAMPLE**~



	Engi	neer	ing	Pi	ping	Syste	m Spe	cifica	ation	Pr No	ojeci	100	009	Project Title	Stai	ndards	Spe Ref.	c.	ACB00	Page 3 of 3
	iteria ning	1/	Carbon Steel / Limitations Of Co On This Page Onl					-	onents 1/2" NS - 4" NS ANSI Class 600 Flange Rating 6" NS - 24" NS Limited By Pipe Wall Thickness						Fo	Remarks: For Other Fabrication				
	Spec. EDS.PIP.51.01				IP.51.01	Fabrica Class	tion Clas Pipin		s 1 Inspe g System And			Spe	pec. EDS.PIP.51.01 Heat Treatment None					Details See Page 2 Of This Specification		
П	N.S. Ra	nge (in) Max			Descripti	on		Standard Number	PCR (Item Code)	П	N.S. R Min	ange (in) Max	1		Descrip	tion			Standard Number	PCR (Item Code)
Pipe	1 2	4	Materi Sched	al Carbon 1.80 THK.	Steel AST	ns to ANSI M A106 Gra	ade B,		PAM80		1 2 6	4 24	Cold Elbo Dime	T CHOICE I Formed Be w, Butt Wel ensions To A M A234 Grad	ding, 45 De ANSI B16. 9	g. Long F , Material:	Radius, Carbon Ste	eel	04 4093	B-5D *EAM45L *EAM90L
	6		Materi			ns to ANSI M A106 Gra			*PAM	BENDS	6	24	Dime	w, Butt Wel ensions To A M A234 Grad	ANSI B16. 9	, Material:	Carbon Ste	eel	04 4093	*EAM90L
/ Caps	1/2	24	Cap, E Materi		ng, Dimens n Steel AS	ions To AN FM A234	SI B16.9	04 4085	*KAM		1 2	4	Elbo Dime ASTI	OND CHOIC w, Butt Wel ensions To A M A234 Grad	ding, 45 De ANSI B16. 9 de WPB, S0	, Material: CHED.80 Ti	Carbon Ste	eel	04 4093	EAM45L80
Joints	1/2	24	Butt W	eld Type '	A'. ICI Sp	ec. EDS.PI	P.51.01		WBA51.01		2	4	Dime	w, Butt Wel ensions To A M A234 Grad	ANSI B16. 9	, Material:	Carbon Ste	eel	04 4093	EAM90L80
s / Pipe Joints	1 2	24		e, Blank, D		To ANSI B n Steel AS		04 2082	*FAM600B	S	1/2	24	B16.	al Tee, Butt . 9, Material: de WPB, As	Carbon St				04 4092	*TAME
Flanges	1/2	24	- B16.	5, Class 6	00,	ensions To M A105, A	ANSI - s Pipe THK	04 2218	FAM600WI	ANCHE	34	24	To A	ucing Tee, E NSI B16. 9, de WPB. Ru	Material: C	arbon Ste	el ASTM A2		04 4095	*TAMR
						Α	SSEMBLY	04 2619		BR	1 2	24		NFORCED B let, Plain Er						*LAN3N
Reducers	34	24	To AN Materi	ISI B16. 9, al: Carbon	Steel AST	entric Dim M A234 Gr End As Pipe	ade WPB.	04 4094	*RAME		1 2 1 2 1 2	24 24 24	ELB:	erial: Carbor OLET, Butt ROLET, But DOLET, Ma	Welding. C t Welding.	arbon Stee Carbon Ste	eel ASTM A			*LANE *LANL *LANW
$\vdash$										П										
Pre Issi	lim ue No								Approved Issue No.								Date STI Copied	D		
Dat	e.								Date.								21-6-90			



	Engi	neer	ing	cifica	ification					
	aterial ning	1 /	Carbon	Steel /	Of Co e On	mponen ly	1/2" NS 6" NS			
ı	brica ec	tion	Spec.	EDS.PIP.51.01	Fabrication Class	s 1 ig Systen	1	Inspe And N		
	N.S. Rai Min	nge (in) Max		Descriptio	on .		Standard Number	Ote	PCR em Code)	
Pipe	1 2	4		eamless, Dimension Carbon Steel ASTN	s to ANSI B36.		Mullibel	PAM	·	
	6	24		amless, Dimension Carbon Steel ASTN 0 THK.				*PAN	Л	
/Caps	1/2	24	Cap, But Material	i <b>nts / Caps</b> it Welding, Dimensi - Carbon Steel AST /PB, As Per THK.		6.9	04 4085	*KAN	νI	
oints	1/2	24	Butt Wel	d Type 'A'. ICI Spe	ec. EDS.PIP.51.	01		WB.	A51.01	
s / Pipe Joints / Caps	<u>1</u> 2	24		Blank, Dimensions 00, Material: Carbor		105.	04 2082	*FAN	/1600B	
Flanges /	1/2	24	- B16.5,	Flange, Welding Neck, Dimensions To ANSI - B16.5, Class 600, Material: Carbon Steel ASTM A105, As Pipe THK					*FAM600WN	
					ASSEM	<b>IBLY</b>	04 2619			
Reducers	3 4	24	To ANSI Material:	r, Butt Welding, Ecc B16. 9, Carbon Steel ASTI nd As Pipe, Small E	M A234 Grade V	VPB.	04 4094	*RAM	ИΕ	



	Engi	neer	ing	Pi	ping (	Syste	m S	pe	cifica	ation	Pr No	oject o.	100	009	Project Title	Star	ndards	Spec. Ref.	ACB0	02 Page 2 of 3		
Des	sign de		AN	SI B31.3 Spec. EDS	S. PIP. 50. 01	Therm Insula	al tion	STD. 18	ec. M5000 1 1620		Sp. Lin	ecifications	on !	ANSI Restr	Class 600 Flan icted to 400 De							
	b / Erect ecificatio	n	$\neg$	Spec. EDS	S. PIP. 51. 01	Tracin	g ¦	Nil				ectrical rthing		Not R	tequired							
	aning &	Protecti	on	Spec. EDS	S. PIP. 51. 01	Testin Shop	g	Nil				neral	$\top$									
	aning &	Protecti	on	Spec. EDS	S. PIP. 57. 01	Testin Site		Sp Hydros	ec. EDS. PIP tatic	. 64. 01		marks	İ									
	N.S. Ra	nge (in) Max			Descripti	on			Standard Number	PCR (Item Code)	Г	N.S. Ra Min	nge (in) Max	-		Descrip	tion		Standard Number	PCR (Item Code)		
П			Situatio	on - A						,	Т			$\vdash$						,		
	1/2	1. 1/2			Outside Screw wheel Operate					VS087				l								
	3	12	Paralle Class A	l Slide Valve, NSI 600, Hand	Rising Stem, F wheel Operate	langed Ends, ed, Cast Steel (	Hytemp)	Body		VS047				l								
			Situatio		•			,						l								
	3/4	2	Paralle Handwl	l Slide Valve, heel Operated	Rising Stem, F , Forged Steel	langed Ends, Body.	Class AN	SI 600,		VS059				l								
s	3	3	Paralle Handwl	l Slide Valve, heel Operated	Rising Stem, F , Cast Steel (H	langed Ends, ytemp) Body.	Class AN	SI 600,		VS047				l								
Valves	4	12	Paralle Handwl	l Slide Valve, heel Operated	Rising Stem, F , Cast Steel Bo	langed Ends, ody.	Class AN	SI 600,		VS048												
	1/2	2	Check \	Valve, Ball Ty d Ends, Class	pe, B.Cover,Ho ANSI 600, Carb	riz., To BS535 on Steel Body	2,			VC218	1											
	3/4	1. 1/2	Uniflow Wrench	Slide Valve, Operated, Ca	Flanged Ends, orbon Steel Bo	Class ANSI 600 dy.	0,			VS043				l								
	3	24	Check \	Valve, Swing d Ends, Class	Type, Bolted C ANSI 600, Cast	over, To BS186 Carbon Steel	8, Body.			VC156												
			Note:-	Use VS043 Fo	r Drain Purpos	es Only.																
Gaskets	1/2	24	S/Steel	Spiral Wound 321 Strip, CA Steel Outer G	d, Inside Bolt C F Filler, Stainl Guide Ring.	Circle To BS338 ess Steel Inner	1, Class Guide R	600, Ring,		GSGSAC600R												
Bolts	1/2	24	Stud Bo Grade I	olt BS4882 Inc 87 Bolt, Grade	h With Nuts, M 2H Nut.	aterial 1% Cro.	Mo. Ste	el	08 0589	*BBAS												
Notes	Valve Stean		ns.		STD 02 01 cordance l		PiP. 30	0. 01			Notes											
	lim ue No									Approved Issue No.								Date STD Copied				
Dat	te.									Date.								21-6-90				



	Engi	neer	ing	Piping Sys	stem	Spe	cific	ation			
Des Co	sign de			ANSI B31.3 Spec. EDS. PIP. 50.01	Thermal Insulation	Sr STD. 18	ec. M5000 1620				
	ab / Erect Spec. EDS. PIP. 51. 01 Tracing Nil										
	aning & ernal	Protecti	on ¦	Spec. EDS. PIP. 51. 01	Testing Shop	Nil					
	aning & ernal	Protecti	on	Spec. EDS. PIP. 57. 01	Testing Site	Sp Hydros	ec. EDS. PIF tatic	P. 64. 01			
	N.S. Rai Min	nge (in) Max		Description			Standard Number	PCR (Item Code)			
			Situa	ation - A							
	1/2	1. 1/2		allel Slide Valve, Outside Screw, Risin s ANSI 600, Handwheel Operated, For				VS087			
	3	12		allel Slide Valve, Rising Stem, Flange s ANSI 600, Handwheel Operated, Cas		np) Body		VS047			
			Situa	ation B+C							
	3/4	2		allel Slide Valve, Rising Stem, Flange dwheel Operated, Forged Steel Body.	d Ends, Class	ANSI 600,		VS059			
es	3	3		allel Slide Valve, Rising Stem, Flange dwheel Operated, Cast Steel (Hytemp)		ANSI 600,		VS047			
Valves	4	12		allel Slide Valve, Rising Stem, Flange dwheel Operated, Cast Steel Body.	d Ends, Class	ANSI 600,		VS048			
	1/2	2	Chec Flan	ck Valve, Ball Type, B.Cover,Horiz., To ged Ends, Class ANSI 600, Carbon Ste	o BS5352, el Body.			VC218			
	3/4	1. 1/2		low Slide Valve, Flanged Ends, Class and Chass and Chass and Chass and Chass and Chass are stated to the Chass and Chass are consistent to the Chass are chasses as a chasse are chasses and chasses are chasses as a chasse are chasses are characteristical charact	ANSI 600,			VS043			
	3	24		ck Valve, Swing Type, Bolted Cover, T ged Ends, Class ANSI 600, Cast Carbo				VC156			
			Note	e:- Use VS043 For Drain Purposes Only	<i>.</i>						
Gaskets	1/2	24	S/Ste		et, Spiral Wound, Inside Bolt Circle To BS3381, Class 600, el 321 Strip, CAF Filler, Stainless Steel Inner Guide Ring, en Steel Outer Guide Ring.						
Bolts	1/2	24	Stud Grad	l Bolt BS4882 Inch With Nuts, Material de B7 Bolt, Grade 2H Nut.	1% Cro. Mo. S	iteel	08 0589	*BBAS			



#### **Pipeline - Maintenance**


# **Check List**

#### Pipeline Hazards Are Not Always Obvious

- 1. Make sure you know what a pipeline contains before starting work on it.
- 2. Ascertain the direction of flow in the pipe
- 3. Check where the pipe is coming from and where it is going to.
- 4. See that all pipelines are safely anchored.
- 5. Be sure you can identify all pipelines and their contents.
- 6. Learn to recognise dangerous leakages, and:
- 7. How to act in an Emergency.
- 8. Note where all the stop valves are.
- 9. Get to know the supervisors responsible for the various pipelines.
- 10. Arrange for the regular emptying of drip-trays under leaks.
- 11. Avoid tripping hazards never leave loose pipes on the floor.
- 12. Make full use of the permit to work system.



# **Pipework**



Follow these simple precautions



Before any work can commence, any or all of the following may be required:

Permit to work PPE requirements

Clearance certificate Breathing apparatus

**Entry permit** Barriers or guards

Hot work permit Lifting equipment


Scheme of work Lagging / trace heating

removal

Method statement Cleaning




# **Before Breaking A Joint**





# When Breaking a Pipe-Joint



**Proceed with the Utmost Caution** 



# When Breaking a Joint

The last bolt should not be slackened until the fox-wedge has been used to open the joint. The line must be Completely Drained.


2nd Bolt to be slackened. Fox-Wedge The Bolt furthest away from you should be slackened FIRST.

3rd Bolt to be slackened.






# When Breaking a Joint



# **Work From Above**


# Never Below





# If The Bolts Are 'Bad'


Renew them one at a time.



**BEFORE THE JOINT IS BROKEN** 



# When Breaking a Joint



Watch Out For Pipe-Spring 'It Happens' When You Least Expect It..




# When breaking joints on liquid lines



**Keep Floors Clear of Corrosive Liquids You Could Get Splashed** 



# **Before Breaking a Joint**



Always Make Sure\_The Pipe-Line is Adequately Supported




# **When Dismantling Pipes Do Not Leave Them Under Your Feet You Will Fall Over** Them. Pipe-work & Valves - 061

©TTE Training Ltd.



# **Before Re-making A Joint**



Clean The Faces Properly "If You Don't It Will Almost Certainly Leak"



#### Identification of Flanges, Fittings and Valves

#### **Pipe Fittings**

Pipes and pipe fittings are marked with the same details. Frequently other information is included, e.g. on an elbow, the angle of the elbow is shown.

#### **Flanges**

The rims of flanges are marked to show:

**Nominal Size.** 

Design Working Pressure in Ibs per sq in.

**Material Type Number.** 

Weight.

#### **Valves**

**Valve Bodies carry the following information:** 

Name of Manufacturer.

**Nominal Size.** 

Design Working Pressure in Ibs per sq in.

A metal disc with the company specification number is attached to the valve.

On the disc are the details of the materials used for the trim of the valve.

'Trim' is the term used for certain working parts of a valve including the stem, seat disc and disc facings.


#### **Screwed and Socket Weld Fittings**

These fittings are marked with the same information as valves, i.e.

Name of Manufacturer.

Nominal Size (bore).

Design Pressure (Ibs per sq in).







# **Blinds & Spacers**

#### **Blinds and Spacers**

When it is necessary to blind-off a line for lengthy periods, a blind is fitted in the line between a pair of pipe flanges.

To make allowances for the blind, a spacer is fitted between the flanges. This is removed when the blind is fitted.






#### Figure of 8 (spectacle) Blinds and Spacers

The figure of 8 blind may be fitted between the flanges of a pipe and a valve connected to a vessel, tank or tower.

When maintenance is necessary and the line is to be closed down without emptying the vessel or tank, the blind side of the figure 8 is swung between the pipe and the valve.

After maintenance, all pipe lines must be pressure tested. The figure 8 blind is used to blank off the valve to prevent it being pressurised and possibly damaged.






## **Recognition of Pipe Fitting**

### **Butt-welding Fittings**

Fitting of this type have bevelled ends for butt welding onto pipes and flanges.

Elbows and bends provide deviations of 90° or 45° in pipework systems.





#### **Elbows**

Long radius elbows have a radius equal to  $1\frac{1}{2}$  times the bore of the pipe.

Short radius elbows have a radius equal to the bore of the pipe

45° elbows allow a pipe deviation of that amount.





#### Note:

The symbols near the illustrations, are used in drawings to, specify the fittings to be used.



## **Pipework**

#### **Tee Branch**

A tee branches the pipe line at 90°. The branches may be equal in diameter or there may be one reducing branch.

The dimensions of a branch are always quoted as:



#### **Reducing Tee Branch**


Reducers are fitted where a change in pipe diameter is required.





Used mainly in horizontal position.

#### **Concentric Reducer**

Used mainly in the vertical position.











**Pipework fittings** 

Elbows Are Available in 90° and 45° Bends


Tees are available With Equal Branches or With a Reducing Branch.






Remember the Branch Dimensions Are Always Quoted in a Particular Sequence: **A** X **B** X **C**.

A Reducer Coupling Is Used Where Change in Pipe Diameter Is Required.







# **Pipework**

Socket Weld Couplings Are Used for Making a Permanent Joint in a Pipe.



#### **Screwed Fittings**


The Cap Is Used for Permanently Blanking off a Pipe.





American Petroleum Institute Standards for Screw Threads on Pipework Are Adopted for All Screwed Connections.

Other Standards are also in common use:

BSPT – British Standard Pipe Thread

















## **Pipework fittings**













Pipe-work & Valves - 069



### **Effects on Pipework**

### Pipework systems need to have flexibility to overcome:

- Water Hammer
- Temperature Changes
- Vibration From Machines

### **How Is This Achieved?**



### **Bellows**


 Expand and contract to overcome the movement of the pipework.

## **Expansion Loop**

 The loop takes up any movement along the pipeline by increasing or decreasing its diameter.



# **Bellows**



Slip Expansion Joint (CutawayView









A corrugated expansion joint consists of a flexible corrugated section which is able to absorb a certain amount of endwise movement of the pipe



Expansion bands make use of pipe fabricated with special bends. The increase in the length of pipe due to expansion is taken up by flexing or springing of the bends. Below are some typical shapes of expansion bends.








©TTE Training Ltd.



# Pipe bending exercise



©TTE Training Ltd.



# Pipe rig exercise – Build, test, dismantle



©TTE Training Ltd.