

Pipework

Aims

At the end of this session the student will have an understanding of the various considerations involved in the design and construction of pipelines.

Pipework

- **Materials**
- **Pipe specifications**
- **Handling of Pipework**
- **Pipe Bending**
- **Threading of Pipework**
- **Flanges (Types & Classifications)**
- **Gaskets**
- **Bolts & Studs**
- **Pipework Erection**
- **Testing**
- **Safe Dismantling**

Pipework

Introduction

Pipework is used to transport chemicals safely from one point to another on chemical plants. Domestic pipes are made from copper, pipework on chemical plants is made from various materials.

Question - *Why?*

Answer

To accommodate a wide variety of conditions and chemicals pipework is made from different materials to different standards of specifications, for example:

(a) Safety - to withstand pressures, temperatures
and to be compatible with the various chemicals
passing through them.

(b) Cost - i.e.. Titanium.

Why is Pipework Used?

To Transfer Liquids, Vapours and Gases.

Materials:

*

- **Mild Steel**
- **Stainless Steel**
- **Cast Iron**
- **Copper**
- **Titanium**
- **Monel**
- **Inconel**

Why Are Pipes Lined?

*

Cost:


*

- **It is cheaper to produce a lining.**

Because

- **A complete pipe is made from more expensive materials.**

Lined Pipework



Types of Linings

- **Rubber**
- **PTFE**
- **PVDF**
- **Alkathene**
- **Bitumen**
- **Lead**
- **Glass**

Pipework Schedules

Refer to the wall thickness of schedule 20, 40, 80 and 160 pipe, as the number increases so does the wall thickness.

The outside diameter remains constant, the bore diameter changes.

Q. Why does the bore change and not the outside diameter?

A. To enable standard fittings to be used.


Pipes Are Measured By Their Nominal Bore Diameter

The pipe wall thickness increases with the increase of schedule number.

Which diameter changes?

The O/D (outside diameter) remains the same so that pipe fittings will fit all schedules

Pipe Schedules



All Flanges Are Selected By Meeting Two Criteria:

1


Safety

(Material, Product, Temperature, etc)


2

Cost


Types of Flange




A. Threaded Flange




B. Welding Neck Flange



C. Slip-on Welding Flange



D. Socket Welding Flange




E. Blind Flange

Flanges

Flanges, like pipes, operate under varying conditions of temperature and pressure.

Standard maximum operating pressure and temperature ratings have been established for flanges and are expressed in pounds per square inch.


**FLANGE DRILLING
B.S.10 TABLE H**



All Dimensions in Inches

Nom Size	O	Bolt Holes		
		No.	Dia.	P.C.D.
½	4½	4	11/16	3¼
¾	4½	4	11/16	3¼
1	4¾	4	11/16	3 7/16
1¼	5¼	4	11/16	3 7/8
1½	5½	4	11/16	4 1/8
2	6½	4	11/16	5
3	8	8	11/16	6½
4	9	8	11/16	7½
6	12	12	7/8	10¼
8	14½	12	7/8	12¾
10	17	12	1	15
12	19¼	16	1	17¼
14	21¾	16	1 1/8	19½
16	24	20	1 1/8	21¾
18	26½	20	1¼	24
20	29	24	1¼	26½
21	30	24	1¼	27½
24	33½	24	1 3/8	30¾


**FLANGE DRILLING
B.S.10 TABLE J**



All Dimensions in Inches

Nom Size	O	Bolt Holes		
		No.	Dia.	P.C.D.
½	4½	4	11/16	3¼
¾	4½	4	11/16	3¼
1	4¾	4	11/16	3 7/16
1¼	5¼	4	11/16	3 7/8
1½	5½	4	11/16	4 1/8
2	6½	4	7/8	5
3	8	8	7/8	6½
4	9	8	7/8	7½
6	12	12	1	10¼
8	14½	12	1	12¾
10	17	12	1 1/8	15
12	19¼	16	1 1/8	17¼
14	21¾	16	1¼	19½
16	24	20	1¼	21¾
18	26½	20	1 3/8	24
20	29	24	1 3/8	26½
21	30	24	1 3/8	27½
24	33½	24	1½	30¾


**FLANGE DRILLING
B.S.10 TABLE D**



All Dimensions in Inches

Nom Size	O	Bolt Holes		
		No.	Dia.	P.C.D.
½	3¾	4	9/16	2 5/8
¾	4	4	9/16	2 7/8
1	4½	4	9/16	3¾
1¼	4¾	4	9/16	3 7/16
1½	5¼	4	9/16	3 7/8
2	6	4	11/16	4½
3	7¼	4	11/16	5¾
4	8½	4	11/16	7
5	10	8	11/16	8¾
6	11	8	11/16	9¾
8	13¼	8	11/16	11½
9	14½	8	11/16	12¾
10	16	8	7/8	14
12	18	12	7/8	16
14	20¾	12	1	18½
15	21¾	12	1	19½
16	22¾	12	1	20½
18	25¼	12	1	23
20	27¾	16	1	25¼
21	29	16	1	26½
24	32½	16	1 1/8	29¾

**FLANGE DRILLING
B.S.10 TABLE E**



All Dimensions in Inches

Nom Size	O	Bolt Holes		
		No.	Dia.	P.C.D.
½	3¾	4	9/16	2 5/8
¾	4	4	9/16	2 7/8
1	4½	4	9/16	3¾
1¼	4¾	4	9/16	3 7/16
1½	5¼	4	9/16	3 7/8
2	6	4	11/16	4½
3	7¼	4	11/16	5¾
4	8½	8	11/16	7
5	10	8	11/16	8¾
6	11	8	7/8	9¾
8	13¼	8	7/8	11½
9	14½	12	7/8	12¾
10	16	12	7/8	14
12	18	12	1	16
14	20¾	12	1	18½
15	21¾	12	1	19½
16	22¾	12	1	20½
18	25¼	16	1	23
20	27¾	16	1	25¼
21	29	16	1 1/8	26½
24	32½	16	1 ¼	29¾


Welding neck flanges are identified by their tapered hubs which connect the flange to the pipe.

Slip on flanges fit onto the end of the pipe and are Fillet Welded into position, back and front.

Screwed or Threaded Flanges are screwed onto the end of the pipe.


Backing Flanges are used with lap joints stubs where frequent dismantling for inspection and cleaning is necessary.

Socket Weld Flanges are slipped onto the ends of pipes and Fillet Welded in position. This type of flange is used for pipework below 38mm (1½inch) Diameter.




Flanges


Flat Face




Lapped




Raised Face




Tongue & Groove



Male & Female




Ring Joint



Different Types of flanges that may be found on site

As you can see each type needs a joint

Flanges



Number of Bolts?

Nominal Bore?

Diameter of
Flange?

Pitch Circle Radius?

Size of Bolt
Holes?

Effects on Pipework

Pipework systems need to have flexibility to overcome:

- **Water Hammer**
- **Temperature Changes**
- **Vibration From Machines**

How Is This Achieved?

Bellows

- **Expand and contract to overcome the movement of the pipework.**

Expansion Loop

- **The loop takes up any movement along the pipeline by increasing or decreasing its diameter.**

Design Considerations When Selecting Joints

- **Line Product**
- **Temperature**
- **Pressure**
- **Materials**
- **Pipe Capacity**
- **Corrosion / Erosion**
- **Insulation Against Thermal Losses**
- **Friction**
- **Pipe Fittings**
- **Pipe Stresses i.e. Supports**
- **Pressure Drop**

Gaskets

A gasket of softer material is fitted between two flanges to ensure a tight joint.

It is placed between the joint surfaces and forms a seal when the joint is tightened.


Different types of gaskets, and materials from which gaskets may be made, are available to suit specified joint requirements.

Depending on the application, the main requirement of a gasket may be any or all of the following:

- **Hardness and Compressibility**
- **Resistance to Heat**
- **Resistance to Pressure**
- **Resistance to Corrosive Action**

It is important that only the gasket specified is fitted otherwise the joint may fail after tightening.

Gaskets



Full-Face Gaskets

The full-face gasket is used with full-face flanges.

The connecting bolts pass through holes in the flanges and gasket.

Full-face gaskets are made from compressed asbestos fibre, or compressed asbestos fibre on a wire mesh or synthetic rubber.

Joints


The type of joint to be used depends on certain things:

1. **Product.**
2. **Temperature.**
3. **Pressure.**
4. **Type of Flange Connection.**

Here Are Some Examples:

Product	Max (operating) Temp	Type of Flange	Type of Gasket
Hydrocarbons Non Corrosive Liquids and Gases (Except - LPG, Ethylene, Fuel Gas, Natural Gas.)	340	ASA 150/300 Raised Face	CAF Jointing Oil Resistant
	675	ASA 300/600 900/1500 Raised Face	Spiral Wound 316/CAF Fill
Steam Up to 35 kg/cm2	340	ASA 150/300 Raised Face	CAF Jointing Oil Resistant
Steam Up to 50 kg/cm2	400	ASA 300/600 Raised Face	Spiral Wound 316/CAF Fill

Joints



Joints & Jointing

Rubber

Applications - Low pressure systems, water, air, uneven flanges.

Advantages -

- **Versatile.**
- **Good Resilience.**
- **Highly Impermeable.**

Joints & Jointing

CAF

Because of the asbestos content, care should be taken to avoid any dust, never file or grind.

Thickness

CAF has little tensile strength. At high pressures a wide joint is more likely to blow than a narrower one.

γ ∞ **Reinforced CAF - Klinger 1000.**

γ ∞ **Klinger 1000.**

γ ∞ **Permatile GT.**

Will tolerate a wide range of chemicals, ie, Nitrogen, Chlorine, Hydrogen, some solvents, Steam and Oil.

γ ∞ **They will withstand temperatures of up to 510°C and pressures of up to 100-bar.**

γ ∞ **All CAF joints should be marked with:**

- a) The Makers Logo.**
- b) The Flange Rating.**
- c) Standard Number.**

Joists & Jointing

SPIRAL WOUND JOINTS

Work through construction:

Windings - Carbon Steel, Monel, Titanium, Nickel,
Stainless Steel and Mild Steel.

Fillers - Asbestos, Lead, PTFE, Masterite,
Ceramic Fibres and Carbon.

Function of the Rings

- 1) Gives strength against line pressure.
- 2) Assists in centralising the joint.
- 3) Limits the amount of compression.

Ringless Joints

" Joint - Compress to 0.100".

~~1 1/8~~ Joint - Compress to 0.135" / 0.145".

~~3~~
~~1 1/2~~ Joint - Compress to 0.180" / 0.190".

Joints & Jointing

PTFE

Advantages:

- **Chemically inert**
- **Easy to cut**
- **No dangerous particles**

Disadvantages:


- **Low co-efficient of friction**
- **Poor resilience (flows under load)**
- **Maximum temperature 300°**

PTFE can be strengthened by:

- a) **Enclosing a steel mesh inside the gasket.**
- B) **Reinforcing the PTFE with glass, metal, etc.**

Joints & Jointing

What Size Gasket?



**Correct
Joint**

**Offer the Joint up to the Flange Face it should look like this.
With the outside of the joint just touching the bolt holes.
The inside of the joint must not protrude into the Pipe Bore.**


Joists & Jointing

Some of the gaskets that you might find on site are:

Spiral Wound Gaskets

1) Type with guide ring.

Guide Ring



Size & Rating Stamped
on Guide Ring


Gasket Face

The type with the guide ring should be used between flat or raised face flanges to ensure true centering and to limit the compression of the gasket.

In addition the guide ring provides extra radial strength and prevents the possibility of a gasket 'blow-out'.

The type with an inner guide ring is used on vacuum service.


Inner Guide Ring



Joints & Jointing


SPADES

To help you find the correct spade. Select a joint that you know to be the right size, place the joint over the spade and make sure the outside diameter is the same.



Joists & Jointing

What Size Gasket?




The Size and Rating is Stamped on the Flange.

Joints & Jointing

Spades

SPECTACLE PLATES



When a spade is in place and needs turning you will have to remove more bolts to allow the spectical blind to rotate.

Joins & Jointing

Spades



Obviously the length of bolt will be longer when a spade needs to be inserted.
Always remember full nuts on each side of the bolt.

Inserting a Spade:

When a spade needs inserting or removing, it is not necessary to remove all the bolts.

Remember This:

Only remove one less than half the amount of bolts in the flange.

E.g. Flange with 4 bolts - Remove 1 Bolt


Flange with 8 bolts - Remove 3 Bolts

Flange with 12 bolts - Remove 5 Bolts

Joists & Jointing

Spades

It is also IMPORTANT to CHECK the WIDTH of a SPADE.



CARBON STEEL SPECTACLE

N.S	150 W	300 W	600 W	900 W
1/2	3/16	1/4	1/4	9/32
3/4	3/16	1/4	1/4	9/32
1	1/4	1/4	1/4	9/32
1 1/2	1/4	5/16	13/32	13/32
2	5/16	5/16	13/32	15/32
3	5/16	3/8	9/16	5/8
4	3/8	3/8	23/32	7/8
6	1/2	5/8	15/16	1 1/8
8	1/2	3/4	1 7/32	1 1/2
10	5/8	7/8	1 1/2	1 13/16

Joints & Jointing

Inside-Bolt Gaskets

Inside-bolt circle gaskets are used with raised-face flanges.

These gaskets fit inside the ring of connecting bolts and against the raised faces of the flanges.

There are two main types of inside-bolt circle gaskets.

1) Raised-Face plain gaskets


These gaskets are made from compressed asbestos fibre or compressed asbestos fibre on wire mesh.

2) Spiral-wound gaskets

These gaskets are made from spiral-wound metal and fibre tapes which are supported in a metal frame.


3) Flat Ring gaskets

This type of gasket is used with tongue and groove flanges. The gasket is made of aluminium, copper or soft steel depending upon its application.




Joists & Jointing

Bolts



Because of the different ranges in temperature and pressure it is important that the correct bolt is used. The most commonly used bolt on site is the 'B7'.


The temperature range for this is approximately - 15 to 400 degrees celcius. The identification mark is stamped on the end of the bolt.



Sizes Given Without Spade


RATING Pipe Size	150		300		600	
	No of Bolts	Bolt Size	No of Bolts	Bolt Size	No of Bolts	Bolt Size
1/2	4	1/2 x 2 1/4	4	1/2 x 2 1/2	4	1/2 x 3
3/4	4	1/2 x 2 1/4	4	5/8 x 2 3/4	4	5/8 x 3 1/4
1	4	1/2 x 2 1/2	4	5/8 x 3	4	5/8 x 3 1/2
1 1/2	4	1/2 x 2 3/4	4	3/4 x 3 1/2	4	3/4 x 4
2	4	5/8 x 3	8	5/8 x 3 1/4	8	5/8 x 4
3	4	5/8 x 3 1/2	8	3/4 x 4	8	3/4 x 4 3/4
4	8	5/8 x 3 1/2	8	3/4 x 4 1/4	8	7/8 x 5 1/2
6	8	3/4 x 3 3/4	12	3/4 x 4 3/4	12	1 x 6 1/2
6	8	3/4 x 4	12	7/8 x 5 1/4	12	1 1/8 x 7 1/2
10	12	7/8 x 4 1/2	16	1 x 6	16	1 1/4 x 8 1/4
12	12	7/8 x 4 1/2	18	1 1/8 x 6 1/2	20	1 1/4 x 8 1/2
14	12	1 x 5	20	1 1/8 x 6 3/4	20	1 5/8 x 9
16	16	1 x 5 1/4	20	1 1/4 x 7 1/4	20	1 1/2 x 9 3/4
18	16	1 1/8 x 5 3/4	24	1 1/4 x 7 1/2	20	1 5/8 x 10 1/2
20	20	1 1/8 x 6	24	1 1/4 x 8	24	1 5/8 x 11 1/4
24	20	1 1/4 x 6 3/4	24	1 1/2 x 9	24	1 7/8 x 12 3/4

Joints & Jointing



Wrong

Joint is too small, therefore, it is not central.



Wrong


Joint is too large and is obstructing the bolt holes.

Joins & Joining

Bolts

Bolts and nuts are made from mild steel and have limited qualities of strength and durability.

The use of bolts is therefore limited to low pressure lines.




Stud Bolts

These are made from higher quality steel than machined bolts and are used at higher pressures.

Stud Bolts are used on high pressure lines, e.g. up to ASA series 1500 flanges.

At one end of the stud bolt is a coded marking which indicates the maximum operating temperature for which the bolt is suitable.



Joints & Jointing

Joint Making Procedure

Ensure joint faces are clean, flat and have the correct surface finish.

Ensure that joint faces are aligned within specified limits.

External pressures should not be applied to align faces prior to bolting and joint face gap should be within specified limits.

Always use the specified jointing material.

Only use specified jointing compound and bolt lubrication.

Bolts should be of the correct specification and fitted in the correct sequence / procedure.

Bolt tension should be applied as specified.

Bolts should be the correct length.


No thread protrusion.

‘Washering up’ should be avoided.

Joints & Jointing

Anti - Seize


Always use anti-seize it saves time in the long run. It is recommended that you only put anti-seize on one side of the bolt. The reason for this is, when the bolt is undone next time, only one nut will come off and this will save you time and effort.



Because of the lagging put the anti-seized part of the bolt next to the obstruction.

Joints & Jointing

Always Clean and Check the Flange Faces



Check for Damage


REPORT IT

If Damage is Spotted

Joins & Jointing

Alignment of Flanges

It is important to align the flanges with each other. If they are not, all of the gasket surface will not be used.





It is most critical that the male and female type of flanges are aligned so that they locate.

Joints & Jointing

Pulling Up The Flange

The gasket must be compressed all the way round. It is important that the flange is pulled up squarely.





Pipe	2" NB SCH 40 Mild Steel
Flanges	ASA 150 2" NB Weld Neck
VB 01	$\frac{1}{2}$ " NB Ball Valve
VC 05	2" NB Check Valve
VW 07	2" NB Wedge Gate Valve
VD 01	1" Diaphragm Valve
VB 01	2" NB Ball Valve
Bolts	5/8 UNC Heavy Series
Joints	ASA 150 2" & 1" CAF

Department	Title	Drawn R. Collins	Drawing No. 0001 / 1
Fabrication & Fitting	Pipe Test-Rig:- 01	Date 10 - 7 - 91	
Tolerances	Material	Scale	Sheet 1 of 1
All Sizes In Millimetres	Mild Steel Pipe SCH 40	Not to Scale	

Piping Systems Specifications

Page 1 of 2

Above Ground Use Only: Index by Fluid - See Also Index by Specification Reference

Fluid Description	Main Pipe Material	Pressure Bar.G	Temperature	SPEC Reference
Air Compressed	C.S	10	50	AMA 004 A
Air Instrument	C.S	10	80	AGB 001 A
Air Instrument	ST.ST. 304L	10	80	SGB 003 A
Air Instrument	ST.ST. 316	10	80	SGD 003 A
Air Mask (Upto Receiver)	C.S	10	80	AMA 025 A
Air Mask (After Receiver)	ST.ST. 304L	7	60	SGB 017 A
Air Mask (After Receiver)	ST.ST. 316	7	60	SGD 017 A
Brine Refrigerated	CS	13.8	+150 -20	AGU 164 A
Dry Risers	CS	7	80	AMA 084 A
Natural Gas	C.S.	10	186	AMA 006 A
Nitrogen	C.S.	10	80	AGB 001 A
Steam Tracing for Wrapping Valves and Fittings	Small Bore Copper (Comp Fittings)	10	186	CZA 001 A
Steam Tracing Direct Clip On	CS	10	186	AMS 001 A
Steam Tracing Spacer	CS	10	186	AMS 002 A
Steam & Condensate L.P. (ANSI 150 Class 3)	CS	10	186	AMA 007 A
Steam & Condensate I.P. (ANSI 300 Class 2)	CS			See Spec HB 007 A
Steam & Condensate H.P. (ANSI 600)	CS			ACB 002 A
Potable Water Before or After BREAK TANK	Copper	8.5	80	CMB 001 A
Potable Water Before or After BREAK TANK	Polypropylene	6.0	20	PMB 003 A
Potable Water Before or After BREAK TANK	C.S Epoxy Lined	10.0	AMB	LMQ 167 A
Potable Water Before or After BREAK TANK	ST.ST. 304L	7.0	80	SMB 001 A
Potable Water Before or After BREAK TANK	ST.ST. 316	7.0	80	SMD 001 A

See Spec HB 007 A

Up to 400°

Engineering		Piping Systems Specification Index					Project No.		T10009		Issue			
		Sheet 1 of 4					Project Title.		Standards		A			
							Pipe Issue Note No.		3117					
See Record Of Modifications Sheet Index For Details Of Any Changes To Index		Fluid Ref.	Main Piping Material.	Pipe.	Flange.	Gaskets.	Shop Test.	Radiography.	Heat Treatment.	Galvanising.	Tracing.	Jacketing.	Insulation.	Painting.
Spec. Ref.	Duty													
ACB002 A	Steam and Condensate H.P. Up To 400° C		CS	A106 GR.B	ANSI 600	SP. WND.		100%					Yes	
AGB001 A	Air - Instrument Nitrogen		CS	API5L GR.B	ANSI 150	CAF		10%						Yes
AGU164 A	Brine - Refrigerated		CS	API5L GR.B	ANSI 150	CAF		10%	See Fab. Spec.				Yes	Yes
AHB007 A	Steam and Condensate I.P. Water - Hot - High Pressure		CS	API5L GR.B	ANSI 300	CAF		10%					Yes	Yes
AMA004 A	Air - Compressed		CS	API5L GR.B	ANSI 150	CAF								Yes
AMA005 A	Water: General Works After Break Tank - Non Potable		CS	API5L GR.B	ANSI 150	CAF							Yes	Yes
AMA006 A	Natural Gas		CS	API5L GR.B	ANSI 150	CAF								Yes
AMA007 A	Steam and Condensate L.P.		CS	API5L GR.B	ANSI 150	CAF							Yes	Yes
AMA025 A	Air Mask - Up To Receiver		CS	API5L GR.B	ANSI 150	Rub- ber								
Issue	A													
Date	3 Sept 1990													

Engineering		Piping System Specification				Project No.	10009	Project Title	Standards	Spec. Ref.	ACB002	Page 2 of 3						
Design Code	ANSI B31.3 Spec. EDS. PIP. 50. 01	Thermal Insulation	Spec. M5000 STD. 18 1620		Specification Limitations	ANSI Class 600 Flange Rating Restricted to 400 Deg. C (87 Bolts)												
Fab / Erect Specification	Spec. EDS. PIP. 51. 01	Tracing	Nil		Electrical Earthing	Not Required												
Cleaning & Protection Internal	Spec. EDS. PIP. 51. 01	Testing Shop	Nil		General Remarks													
Cleaning & Protection External	Spec. EDS. PIP. 57. 01	Testing Site	Spec. EDS. PIP. 64. 01 Hydrostatic															
N.S. Range (in)		Description				Standard Number		PCR (Item Code)		N.S. Range (in)		Description		Standard Number		PCR (Item Code)		
Min	Max									Min		Max						
Valves	1/2	1. 1/2	Parallel Slide Valve, Outside Screw, Rising Stem, Flanged Ends, Class ANSI 600, Handwheel Operated, Forged Steel Body.				VS087											
	3	12	Parallel Slide Valve, Rising Stem, Flanged Ends, Class ANSI 600, Handwheel Operated, Cast Steel (Hytemp) Body				VS047											
	3/4	2	Parallel Slide Valve, Rising Stem, Flanged Ends, Class ANSI 600, Handwheel Operated, Forged Steel Body.				VS059											
	3	3	Parallel Slide Valve, Rising Stem, Flanged Ends, Class ANSI 600, Handwheel Operated, Cast Steel (Hytemp) Body.				VS047											
	4	12	Parallel Slide Valve, Rising Stem, Flanged Ends, Class ANSI 600, Handwheel Operated, Cast Steel Body.				VS040											
	1/2	2	Check Valve, Ball Type, B.Cover, Horiz., To BS5352, Flanged Ends, Class ANSI 600, Carbon Steel Body.				VC210											
	3/4	1. 1/2	Uniflow Slide Valve, Flanged Ends, Class ANSI 600, Wrench Operated, Carbon Steel Body.				VS043											
	3	24	Check Valve, Swing Type, Bolted Cover, To BS1868, Flanged Ends, Class ANSI 600, Cast Carbon Steel Body. Note:- Use VS043 For Drain Purposes Only.				VC156											
Gaskets	1/2	24	Gasket, Spiral Wound, Inside Bolt Circle To BS3381, Class 600, S/Steel 321 Strip, CAF Filler, Stainless Steel Inner Guide Ring, Carbon Steel Outer Guide Ring.				GSGSAC600R											
Bolts	1/2	24	Stud Bolt BS4882 Inch With Nuts, Material 1% Cro. Mo. Steel Grade B7 Bolt, Grade 2H Nut.				08 0589		*BBAS									
Notes	Valve Selection Based On STD 02 0113 Steam Traps: Select in Accordance With EDG. PIP. 30. 01										Notes							
Prelim Issue No.								Approved Issue No.								Date STD Copied		
Date.								Date.								21-6-90		

Note: For Items Outside The Scope of This Specification Consult Piping Section *PCR = Short Code

Note: For Items Outside The Scope of This Specification Consult Piping Section


Check List

Pipeline - Maintenance

1. **Make sure you know what a pipeline contains before starting work on it.**
2. **Ascertain the direction of flow in the pipe**
3. **Check where the pipe is coming from and where it is going to.**
4. **See that all pipelines are safely anchored.**
5. **Be sure you can identify all pipelines and their contents.**
6. **Learn to recognise dangerous leakages, and:**
7. **How to act in an Emergency.**
8. **Note where all the stop valves are.**
9. **Get to know the supervisors responsible for the various pipelines.**
10. **Arrange for the regular emptying of drip-trays under leaks.**
11. **Avoid tripping hazards - never leave loose pipes on the floor.**
12. **Make full use of the permit to work system.**

Pipeline Hazards Are Not Always Obvious

Before Breaking A Joint




**Check That The Line
Is Completely Drained**

Pipework



Follow These Simple Precautions

When Breaking a Pipe-Joint




**Always Assume the
Pipe is Full**

Proceed with the Utmost Caution

When Breaking a Joint

The last bolt should not be slackened until the fox-wedge has been used to open the joint. The line must be Completely Drained.




3rd Bolt to be slackened.


DO IT THE SAFE WAY

When Breaking a Joint

Work From Above




**Never
Below**




If The Bolts Are 'Bad'

**Renew them one at a time.
In the correct sequence.**



BEFORE THE JOINT IS BROKEN


When Breaking a Joint



**Watch Out For Pipe-Spring 'It Happens'
When You Least Expect It..**

When Breaking Joints On Liquid Lines


**Always Use a Tundish to Drain
Away Residue**



**Keep Floors Clear of Corrosive Liquids You Could Get
Splashed**




Before Breaking a Joint



Always Make Sure
The Pipe-Line is adequately supported


When Dismantling Pipes

**Do Not
Leave Them
Under Your Feet**



**You Will
Fall Over
Them.**

Before Re-making A Joint



Clean The Faces Properly

**“If You Don’t
It Will Almost Certainly Leak”**

Identification of Flanges, Fittings and Valves

Pipe Fittings

Pipes and pipe fittings are marked with the same details.
Frequently other information is included, e.g. on an elbow, the angle of the elbow is shown.

Flanges

The rims of flanges are marked to show:

Nominal Size.

Design Working Pressure in *lbs per sq in.*

Material Type Number.

Weight.

Valves

Valve Bodies carry the following information:

Name of Manufacturer.

Nominal Size.

Design Working Pressure in *lbs per sq in.*

A metal disc with the company specification number is attached to the valve.

On the disc are the details of the materials used for the trim of the valve.

‘Trim’ is the term used for certain working parts of a valve including the stem, seat disc and disc facings.


Screwed and Socket Weld Fittings

These fittings are marked with the same information as valves, i.e.

Name of Manufacturer.

Nominal Size (bore).

Design Pressure (*lbs per sq in.*).



Blinds & Spacers

Blinds and Spacers

When it is necessary to blind-off a line for lengthy periods, a blind is fitted in the line between a pair of pipe flanges.

To make allowances for the blind, a spacer is fitted between the flanges. This is removed when the blind is fitted.






Figure of 8 (spectacle) Blinds and Spacers

The figure of 8 blind may be fitted between the flanges of a pipe and a valve connected to a vessel, tank or tower.

When maintenance is necessary and the line is to be closed down without emptying the vessel or tank, the blind side of the figure 8 is swung between the pipe and the valve.

After maintenance, all pipe lines must be pressure tested. The figure 8 blind is used to blank off the valve to prevent it being pressurised and possibly damaged.



Recognition of Pipe Fitting

Butt-welding Fittings

Fittings of this type have bevelled ends for butt welding onto pipes and flanges.

Elbows and bends provide deviations of 90° or 45° in pipework systems.

Elbows



Long radius elbows have a radius equal to 1½ times the bore of the pipe.

Short radius elbows have a radius equal to the bore of the pipe.

45° elbows allow a pipe deviation of that amount.

Note:

The symbols near the illustrations, are used in drawings to, specify the fittings to be used.



Pipework

Tee Branch

A tee branches the pipe line at 90°. The branches may be equal in diameter or there may be one reducing branch.

The dimensions of a branch are always quoted as:

AxBxC

Reducing Tee Branch





Reducers are fitted where a change in pipe diameter is required.

Eccentric Reducer

Used mainly in horizontal position.


Concentric Reducer

Used mainly in the vertical position.




Pipework

Tees are available With
Equal Branches or With
a Reducing Branch.
Remember the Branch
Dimensions Are Always
Quoted in a Particular
Sequence:
A X B X C.




A Reducer Coupling Is Used Where
Change in Pipe Diameter Is
Required.




Pipework

Socket Weld Couplings Are Used for Making a Permanent Joint in a Pipe.





Screwed Fittings

The Cap Is Used for Permanently Blanking off a Pipe.



Unions Are Inserted in a Pipeline Where a Break in the Line Is Required.



In General, the Use of Screwed Fittings Is Restricted to the Smaller Pipe Sizes 38mm (1½ in And Below) Because Other Joining Methods Are More Practical and Economical.




American Petroleum Institute Standards for Screw Threads on Pipework Are Adopted for All Screwed Connections.


Pipework




45° ELBOW




TEE




UNION



SWAGE REDUCER



REDUCER



COUPLING

Process Valves

- **Types**
- **Classification**
- **Materials of Construction**
- **Operations**
- **Identification**
- **Uses and Limitations**
- **Faults**
- **Variations**